

CAUTION: EXTERNAL ILLUMINATION SOURCE REQUIRED

**LISTED FOR OUTDOOR WET LOCATIONS
SUITABLE FOR FLOOR PROXIMITY INSTALLATION
IMPORTANT SAFEGUARDS. READ AND
FOLLOW ALL SAFETY INSTRUCTIONS.**

SPECIFICATIONS:

The sign must be charged for a minimum of 60 minutes to become fully operational.
External illumination source must be reliable and supplied by a circuit not controlled by an automatic timer or sensor and whose controls are accessible only to authorized personnel.
External illumination source is to be energized at all times during building occupancy.
Lighting levels on the sign face(s) should be confirmed after any change in external lighting.
It is recommended that periodic inspections be performed in accordance with applicable codes.
Install this sign indoors or outdoors.

ACTIVATION:

CAUTION—MINIMUM 5 FOOT-CANDLES (54 LUX) OF EXTERNAL UNFILTERED FLUORESCENT ILLUMINATION MUST BE PRESENT ON THE SIGN FACE AT ALL TIMES DURING BUILDING OCCUPANCY.

VIEWING DISTANCE:

100-FOOT VIEWING DISTANCE

INSTALLATION:

Four studs provided. Thread the studs in the 4 corners of sign where inserts are located. Take mounting template place where sign desired and level. Drill holes where indicated, place silicone adhesive on each stud and install on wall. Designed for wall, ceiling or flag mounting—**mounting bracket available.**

CLEANING:

Cleaning of the sign face should be done with a non-abrasive cloth dampened with water.
Do not use chemical solvents.

EXIT SIGN MODEL NUMBERS (PM100)

Model # 7070-B	Complete single sided EXIT sign kit for Right, Left, Double Arrow or EXIT only sign with Red Background
Model # 7072-B	Complete double sided EXIT sign kit for Right, Left, Double Arrow or EXIT only sign with Red Background
Model # 7080-B	Complete single sided EXIT sign kit for Right, Left, Double Arrow or EXIT only sign with Green Background
Model # 7082-B	Complete double sided EXIT sign kit for Right, Left, Double Arrow or EXIT only sign with Green Background
Model # 7090-B	Complete single sided EXIT sign kit for Right, Left, Double Arrow or EXIT only sign with Black Background
Model # 7092-B	Complete double sided EXIT sign kit for Right, Left, Double Arrow or EXIT only sign with Black Background

SAVE THESE INSTRUCTIONS